



RMVE-1D 120V
RMVE-2D 230V
RMVE-9D 100V
COMPLETE REWORK STATION
WITH PNEUMATIC PUMP

SPARE PARTS	
DDE-1B / DDE-2B / DDE-9B:	
-REAR CIRCUIT	0018129
-ENCLOSURE	
· TOP	0019028
· BOTTOM	0014567
· FRONT+DISPLAY	0016312
· BACK	0013413
MVE-A:	
-CIRCUIT	0014059
-ENCLOSURE	
· TOP	0014860
· BOTTOM	0014861
· FRONT	0014688
· BACK	0014862
-SOLENOID VALVE	0006813

SPARE PARTS	
JTSE-1A / JTSE-2A	
-ENCLOSURES:	
· TOP	0019028
· BOTTOM	0013486
· FRONT+DISPLAY	0016862
· BACK	0016812
JTSE-1A	
-CIRCUIT	0017185
-SUCTION PUMP	0008723
-HOT AIR PUMP	0015970
JTSE-2A	
-CIRCUIT	0017671
-SUCTION PUMP	0008722
-HOT AIR PUMP	0015970

DDE-1B 120V FUSE T-4A
 DDE-2B 230V FUSE T-2A
 DDE-9B 100V FUSE T-5A

JTSE-1A 120V FUSE T-8A
 JTSE-2A 230V FUSE T-4A



DDE-1B / DDE-2B / DDE-9B

JTSE-1D / JTSE-2D

